

INSTALLATION INSTRUCTIONS


MEGA MAX FULL ALUMA-CRETE CUBE ANCHOR

ANCHOR TYPE: Above ground base

CONSTRUCTION: Galvanized steel frame, pavers, galvanized steel plates, aluminum full above ground cover, polished stainless steel hinge plate


WIND LOAD: Suitable for winds up to 25 mph. Close when not in use, during storms, and at night

Assemble as viewed below




MEGA MAX FULL ALUMA-CRETE CUBE ANCHOR


Assemble as viewed below




845 LBS
8 PAVERS
FOR USE WITH 16.0' SQ, 16.0' RND



1100 LBS
12 PAVERS
FOR USE WITH 18.0' SQ, 20.0' RND
OR SMALLER



1365 LBS
12 PAVERS & 4 GVS PLATES
FOR USE WITH 20.0' SQ, 24.0' RND,
14.0' X 20.0' RECT
OR SMALLER





1885 LBS
10 PAVERS & 14 GVS PLATES
FOR USE WITH 24.0' SQ,
16.0' X 24.0' RECT
18.0' X 24.0' RECT
OR SMALLER

MEGA MAX FULL ALUMA-CRETE CUBE ANCHOR




Assemble as viewed below

INSTALL THE STAINLESS STEEL SECURITY STEM TO THE STAINLESS STEEL HINGED SURFACE ANCHOR USING THE HARDWARE PROVIDED



Secure full above ground cover using six screws.

screw 1/4-20x1/2" (x2)




screw 1/4-20x1/2" (x4)

MEGA MAX FULL ALUMA-CRETE CUBE ANCHOR

IF APPLICABLE: STEPS FOR PARASOL WITH ELECTRICAL SYSTEMS

Once the parasol is installed onto the full above ground cover, carefully route electrical cords as shown. The frame and front full above ground cover have cutouts to route the wires.



Secure full above ground cover using six screws.

Note: Above ground covers must be installed after parasol has been lifted.

